

Mitel 5000 Voicemail Playback Options

While listening to a voicemail, you may use the following options:

Digit	Action
1	Rewind
2	Pause
3	Forward
4	Lower Volume
5	Play Message Envelope
6	Raise Volume
7	Save Message
8	NO ACTION
9	Delete Message
0	Help Menu
*	Return to Previous Menu
#	Skip to End of Message